



ROBERTS GORDON®

UltraVac™

Controls for Modulating CORAYVAC® Infrared Heating Systems

Software Installation & Operation Manual



⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can result in death, injury or property damage. Read the Installation, Operation and Service Manual thoroughly before installing or servicing this equipment.

Installation must be done by a contractor qualified in the installation and service of gas-fired heating equipment or your gas supplier.

Installer

Please take the time to read and understand these instructions prior to any installation. Installer must give a copy of this manual to the owner.

Owner

Keep this manual in a safe place in order to provide your serviceman with necessary information.



Roberts-Gordon LLC

1250 William Street
P.O. Box 44
Buffalo, New York 14240-0044
Telephone: +1.716.852.4400
Fax: +1.716.852.0854
Toll Free: 800.828.7450

www.rg-inc.com
www.corayvac.com
www.radiantheaters.com

TABLE OF CONTENTS

SECTION 1: Introduction	1
1.1 General Information	1
1.2 System Software	1
1.3 Communications Bus Wiring	1
1.4 PC Requirements	2
1.5 Safety	2
SECTION 2: Getting Started	3
2.1 Communication Methods	3
2.2 Installing ROBERTS GORDON® ULTRAVAC™ Software	6
2.3 Software "Connect" Window	6
SECTION 3: Program Menu	8
3.1 ROBERTS GORDON® ULTRAVAC™ Setup Screen	8
3.2 Time Schedules	9
3.3 Setpoint Setup	11
3.4 Setpoint Range	13
3.5 Input/Output Titles	14
3.6 Holiday Schedule	16
3.7 Timed Overrides	17
3.8 Sensor Setup	18
3.9 Global I/O Setup	20
3.10 History Mode	21
3.11 Time/Date	22
SECTION 4: Status Menu	23
4.1 Board Status	23
SECTION 5: Graphics Menu	24
5.1 Programming Mode	24
5.2 Status Mode	30
SECTION 6: Alarms Menu	31
6.1 Temperature Alarms	31
SECTION 7: History Menu	33
7.1 Retrieve History Data to File	33
SECTION 8: Communications Menu	35
8.1 Connect	35
8.2 Send File Data to Controller	35
8.3 Retrieve Controller Data to File	35
8.4 Hang-up	36
SECTION 9: File Menu	37
9.1 New Job	37
9.2 Open Job	38
9.3 Edit Job	38
9.4 Delete Job	39
SECTION 10: Multiple Controllers	40
10.1 Copying board1.TMS Board File for Jobs with Multiple Controllers	40
10.2 Outside Air Temperature Setup for Satellite Controllers	42
SECTION 11: Manual On/Off Screen	43
SECTION 12: TCP/IP (LAN) Communication Module Installation	45
12.1 Module Details	45
12.2 TCP/IP Communication Module	46
12.3 Network Communications Connection	47
SECTION 13: TCP/IP (LAN) Communication Module	48
13.1 Set the Software Communications Parameters	48
13.2 Set the System Type	49

© 2011 Roberts-Gordon LLC

All rights reserved. No part of this work covered by the copyrights herein may be reproduced or copied in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without the written permission of Roberts-Gordon LLC.

13.3 Connect to the TCP/IP Communication Module	50
13.4 Retrieve the Existing TCP/IP Module Settings	52
13.5 Enter the New TCP/IP Communication Module Settings	54
13.6 Download the New Module Settings	55
13.7 Completing the Installation	56
SECTION 14: BACnet® Controller Programming	57
14.1 PC Requirements	59
14.2 Communication Method	59
14.3 Installation and Setup	59
SECTION 15: Troubleshooting	61
15.1 Unable to Connect	61
15.2 Sensor Temperatures	61
15.3 Zone Status On/Off	61
15.4 Graphics Distorted	61
15.5 Temperature Alarms Reset	61
15.6 Setting Changes Not Saved	61
15.7 Current Conditions Are Not Updating	61
15.8 BACnet® Controller	62
15.9 Burner or Pump Operation	62
SECTION 16: The ROBERTS GORDON® ULTRAVAC™ License Agreement	63

There are references in this manual to various trademarks. All trademarks mentioned herein, whether registered or not, are the property of their respective owners. Roberts-Gordon LLC is not sponsored by or affiliated with any of the trademark or registered trademark owners, and make no representations about them, their owners, their products or services. Roberts-Gordon LLC is not sponsored by or affiliated with BACnet®.

TABLE OF FIGURES

Figure 1: Software Connect Window	6
Figure 2: ROBERTS GORDON® ULTRAVAC™ Setup	8
Figure 3: Time Schedules	9
Figure 4: Setpoint Setup	11
Figure 5: Setpoint Range	13
Figure 6: Input/Output Titles	14
Figure 7: Holiday Schedules	16
Figure 8: Timed Overrides	17
Figure 9: Sensor Setup	18
Figure 10: Global Setup	20
Figure 11: History Mode	21
Figure 12: Time/Date	22
Figure 13: Board Status	23
Figure 14: Graphics Edit Box Type Drop Down	25
Figure 15: Graphics Setup Buttons	26
Figure 16: Graphic Example	27
Figure 17: Graphics Analog Input Box	28
Figure 18: Graphic Example with Data Boxes	30
Figure 19: Alarm Selection	31
Figure 20: Temperature Alarms	32
Figure 21: History - Retrieve Data to File	33
Figure 22: History - Data File Name	34
Figure 23: Send File to Controller	35
Figure 24: Hang-Up	36
Figure 25: File Drop Down Menu	37
Figure 26: New Job System Setup	37
Figure 27: Edit Job	38
Figure 28: Add New Board File	39
Figure 29: Selecting Board 2 File	41
Figure 30: Satellite Controller Outside Air Sensor Setup	42
Figure 31: ON/OFF Screen	43
Figure 32: TCP/IP Communication Module Details	45
Figure 33: Power Connection to Central Control Board	46
Figure 34: 9 Pin Adapter for PC	50
Figure 35: Toggle the Program Switch	52
Figure 36: Communication Port Connections	56
Figure 37: BACnet® Order Form	58
Figure 38: Field Server Information	60
Figure 39: Change IP Address	60

SECTION 1: INTRODUCTION

1.1 General Information

The ROBERTS GORDON® ULTRAVAC™ Controller is designed for multi-stage control of heating. This controller is a microprocessor based control package designed for modulating control of CORAYVAC® heaters based on outdoor temperatures. The CORAYVAC® system input modulates continuously (not staged) between 60% and 100% of designed system input. Input modulation is controlled by varying both air and gas flow rates through the burners.

Multi-function electronic air sensors display zone air temperature, provide zone occupancy override feature and provide user-defined limited zone setpoint adjustment. The ROBERTS GORDON® ULTRAVAC™ is also available with BACnet® interface capabilities, allowing your CORAYVAC® system with ULTRAVAC™ Controls to interface with other BACnet® building management control platforms.

1.2 System Software

System status and settings are viewed from a PC (not supplied) running ROBERTS GORDON® ULTRAVAC™ Software. The software for the ROBERTS GORDON® ULTRAVAC™ Controller is supplied on CD ROM. This includes:

- URV Software: A setup.exe for installation ULTRAVAC™ Controller and Manuals.
- BACnet® Software: A ruinet.exe for installation ULTRAVAC™ BACnet® Controller and Manuals.

The software keeps the user informed of system function by displaying features such as:

- Current room temperature for each zone (°F or °C).
- Current outdoor air temperature (°F or °C).
- Setpoint Temperatures (°F or °C) - for each occupied zone.
- Setback Setpoint Temperature (°F or °C) - Unoccupied periods automatically maintain setback temperature.
- Time Schedule - 7-day scheduling screen for each individual zone, four available occupied time periods per zone.
- Holiday Schedule - Holiday scheduling screen for each individual zone.
- Modulating 0-10Vdc output signal for modulating pump speed.
- Heat Power ON/OFF Indication (For Each Individual Zone)
- Safety Switch Position
- Pump Power ON/OFF Indication
- Pump Speed

1.3 Communications Bus Wiring

- RS-485 communications allowing for system control and status viewing from an on-site PC.
- Modem communication package allowing for system control and status viewing from an on-site. Systems utilizing the optional modem offer pager notification and messaging for customized systems alarms.

1.4 PC Requirements

ROBERTS GORDON® ULTRAVAC™ Software requires a PC (not supplied) running Windows® 95 or higher, with a Pentium® class processor and at least 64k of RAM.

1.5 Safety

Your Safety is Important to Us!

Read this manual carefully before installation, operation, or service of this equipment. Installation, service and annual inspection of controller must be done by an electrician qualified in the installation and service of control systems for heating equipment.

Installation Code and Annual Inspections: All Installations of ROBERTS GORDON® products must be performed by a contractor qualified in the installation and service of gas-fired heating equipment and conform to all requirements of all applicable governmental authorities pertaining to the installation and operation of the equipment.


For optimum performance and safety, Roberts-Gordon recommends that a qualified contractor annually inspect your ROBERTS GORDON® products and perform service where necessary, using only ROBERTS GORDON® replacement parts. Also, know and maintain heater clearances to combustibles, see heater Installation, Operation and Service manual for further details. If you require additional manuals, contact your ROBERTS GORDON® independent distributor or Roberts-Gordon at (716) 852-4400 or (800) 828-7450 in the U.S. or at www.rg-inc.com.

SECTION 2: GETTING STARTED

2.1 Communication Methods


ROBERTS GORDON® ULTRAVAC™ is shipped with PC software that allows the user to monitor and communicate to the ROBERTS GORDON® ULTRAVAC™ controllers in the building. The PC can be connected to the controllers by various methods.

2.1.1 Modem (Included with Central Controller)




The PC with a modem can dial directly into the central controller (controller #1) with the modem chip (P/N 10080142) installed on the central control board. If more than one controller is installed in the building, additional modems are not needed. The PC will be able to communicate to all the controllers. The RS-485 communications terminals on all the controllers are wired in series with the central controller so that all controllers can send information through the central controller to the PC.

2.1.2 RS-485 Converter (Optional with Central Controller)




The PC can communicate to the central controller with the optional RS-485 converter (P/N 10080430) wired to the central controller and plugged into the PC 9-pin serial port. If more than one controller is installed in the building, the PC will be able to communicate to all the controllers. The RS-485 communications terminals on all the controllers are wired in series with the central controller so that all controllers can send information through the central controller to the PC.

2.1.3 Direct Connect (Included with Central Controller)



This method is only used when the PC is in close proximity [within 50' (15 m)] of a controller, or for troubleshooting at the controller using a laptop PC. A standard 4-wire phone cable is run between the PC and the controller. The phone cable plugs directly into the controller's direct connect port. The other end of the phone cable plugs into a 9 pin serial port adapter and the adapter plugs into one of the PC's 9-pin serial ports. One direct connect cable package (P/N 10080410) consisting of a 9 pin adapter and 7' (2 m) phone cable is supplied with the ROBERTS GORDON® ULTRAVAC™ central controller package.

2.1.4 TCP/IP (LAN) Communication Module (Optional with Central Controller)




Multiple PCs can communicate to the central controller with the optional TCP/IP (LAN) communication module installed at the central controller. If more than one controller is installed in the building, the PCs (one at a time) will be able to communicate to all the controllers. The RS-485 communications terminals on all the controllers are wired in series with the central controller so that all controllers can send information through the central controller to the PC.

Any PCs desired for communication to the ULTRAVAC™ controllers must have the ULTRAVAC™ software installed.

The TCP/IP (LAN) communication module requires an initial set up and programming operation. Contact your system administrator for assistance. See *Section 12* and *Section 13* for details.

2.1.5 Direct Connect PC with ULTRAVAC™ BACnet® Controller



The PC can be connected to the ULTRAVAC™ BACnet® Controller by using a standard ethernet cable.

2.2 Installing ROBERTS GORDON® ULTRAVAC™ Software



Insert the ULTRAVAC™ Software CD into the CD drive of the PC. If software does not load automatically, click on the "My Computer" icon. Double click on your CD drive. Double click on the Setup.exe file. Follow the on-screen directions. When the installation is complete, a black "RG" icon titled "UltraVac" will appear on your desktop.

If using a TCP/IP (LAN) communication module, skip to *Section 12* and *Section 13* before preceding to *Section 2.3*.

FIGURE 1: Software Connect Window

2.3 Software "Connect" Window

Double click on the UltraVac icon on the desktop. The software will open and the "Connect" window will appear.

If the job only has ONE controller, the default job file (UltraVac DEMO) can be used as the job file, but rather than using the default file, it is recommended to create a new project specific job file.

To use default job name, double click on the file "UltraVac DEMO" in the white box underneath the "Setup String" drop down. "UltraVac DEMO" will appear in the "System Name" box. See *Page 7, Section 2.3.2*.

If the job has MORE THAN ONE controller installed, or to create a new job file for a single controller job, See *Page 37, Section 9.1*.

2.3.1 Direct Port and Modem Port

Using the drop downs for "direct port" and "modem port", select the PC port number that will be used for the RS-485 Converter, Direct Connect adapter or Modem. If connection is made via the TCP/IP (LAN) communication module, the "direct port" and "modem port" dropdowns are not used. The "direct port" drop down is used for selecting the ports for either the RS-485 Converter or the Direct Connect plug to the PC. If the PC port number is not known, start by selecting port #1 from the appropriate drop down. If a connection

can not be made, double click on the "Hang-up" button and select the next port number.

2.3.2 Direct Connect Button

If connecting via Direct Connect or RS-485 Converter, select the port number from the "Direct Port" drop down. Select the baud rate from the baud rate drop down or overwrite the existing number. Use **19200 baud for direct connect**, use **57600 baud for RS-485 connection**. Click on the "Direct Connect" button.

If the connection is unsuccessful, check the wiring connections or double-click the "Hang-up" button and select a new port number on the "Direct Port" drop down. Upon successful connection, "Connected to TMS150" will appear in the "Connection Status" panel as shown on *Page 6, Figure 1*.

Click Exit.

2.3.3 Modem Connect Button

If connecting via modem, select the port number from the "Modem Port" drop down. Select the modem type that is used in the PC from the "Modem Type" drop down. Upon selection, the "Setup String" will be automatically selected. Select the appropriate baud rate for the PC modem type from the "Baud Rate" drop down, if the modem baud rate is higher than 2400 baud, select 2400. Type the phone number of the phone line connected to controller #1 in the "Phone #" field. Click "Modem Connect."

NOTE: Phone number format is "xxx-xxx-xxxx". Remove area code for local calls.

If the connection is unsuccessful, check wiring connections or double-click the "hang-up" button and select a new port number on the "Modem Port" drop down.

Upon successful connection, "Connected to TMS150" will appear in the "Connection Status" window as shown on *Page 6, Figure 1*.

Click Exit.


2.3.4 Internet Connect Button

If connecting via TCP/IP (LAN) Communication Module, complete *Section 12* and *Section 13* before attempting to connect.

Type the module's IP address in the "IP address" field. **Select 57600 baud** in the "Baudrate" dropdown. Click on the "Internet Connect" button.

If the connection is unsuccessful, check wiring connections, entered IP address and entered port number (in the "Port Field", not the "Direct Port" drop down). See *Page 54, Section 13.5*. Upon successful connection, "Connected to TMS150" will appear in the "Connection Status" window as shown on *Page 6, Figure 1*.

Click exit.




SECTION 3: PROGRAM MENU

3.1 ROBERTS GORDON® ULTRAVAC™ Setup Screen

On the menu bar, click on "Program."

On the drop down menu, click on "UltraVac Setup."

FIGURE 2: ROBERTS GORDON® ULTRAVAC™ Setup




Click on the "Edit" button.

Enter the "External Design Temperature" and "Internal Design Temperature." These values were used to calculate the heat loss of the building during the design of the ROBERTS GORDON® ULTRAVAC™ heating system. For optimal performance of the ROBERTS GORDON® ULTRAVAC™ system, contact your local distributor or designing engineer for the correct External and Internal Design temperatures.

Enter the "Modulation Override." This is the number of degrees below the temperature setpoint at which the heating system will increase heat output to 100% to recover from a rapid heat loss in the heating zone. To allow the system to modulate between 60% output and 100% output correctly, do not select a number less than 2°F. Generally a value of 3°F or 4°F will allow quick enough response to rapid building heat loss without increasing system output to 100% if the zone temperature dips 1°F or 2°F below the setpoint.

Click on the "Send to Controller" button to send the design temperature and modulation override values to the controller. Click on the green "Exit" button. **While the controller is communicating with the PC, the green "Exit" button will become a red "Updating" button. You must wait until the button is green before clicking "Exit".**



3.2 Time Schedules

Each heating zone has four available "occupied" time periods. An occupied period is a time period in which the zone will be satisfying an "occupied" temperature setpoint. If no occupied periods are scheduled, the zone will be satisfying a "setback" temperature setpoint.

On the menu bar, click on "Program." On the drop down menu, click on "Time Schedules". Click on the "Edit" button.

FIGURE 3: Time Schedules

Time Schedules

Special Schedules

	1	2	3	4
Mon	01	00	00	00
Tue	01	00	00	00
Wed	01	00	00	00
Thur	01	03	00	00
Fri	01	00	00	00
Sat	02	00	00	00
Sun	00	00	00	00

☒ Enabled

Output in Process

☒ Heater Zone 1
☐ Heater Zone 2
☐ Heater Zone 3

Enter Schedules

	On	Off
1.	09:00	18:00
2.	09:00	12:00
3.	20:00	23:59
4.	00:00	00:00
5.	00:00	00:00
6.	00:00	00:00
7.	00:00	00:00
8.	00:00	00:00
9.	00:00	00:00
10.	00:00	00:00
11.	00:00	00:00
12.	00:00	00:00

Buttons: Send To Controller, Exit

In the "Enter Schedules" panel, type in any desired occupied time periods, use the 24 hour clock (i.e. 1:15pm = 1315). Twelve different schedules can be entered.

In the "Output in Process" panel, click on the Heating Zone desired. In the "Special Schedules" panel, type in the schedule number(s) (located in the "Enter Schedules" panel) that apply to the needed schedules for each day of the week for the selected zones. Use two digit numbers, i.e. enter "01" for schedule #1. The first scheduled "occupied" period of each day should be entered into period 1. Additional schedules for that day should be entered in periods 2-4 in the order in which they occur during the day. For any unused periods, enter "00." Every day does not need to have schedules entered.

The zone will maintain the setback temperature until a scheduled period occurs. Remember to set schedules for all heating zones by clicking on other zones in the "Output in Process" area.


Click the "Enabled" box to activate the schedule times. If the "Enabled" box is not checked, the zone will only satisfy setback temperatures, occupied times will not be activated.

**For unused heating zones, select the zone in the "Output in Process" panel.
Set all time schedules (1-4) for Monday - Sunday to "00".**

After Scheduling all the heating zones, click on the "Send to Controller" button.

Click on the green "Exit" button.

Example: (See *Page 9, Figure 3*) Monday-Friday workers occupy Zone 1 from 9 am to 6 pm and 9 am to 12 pm on Saturday. On Thursday nights, an additional shift works from 8 pm to 12 am.



3.3 Setpoint Setup

On the menu bar, click on "Program." On the drop down menu, click on "Setpoint Setup." Click the "Edit" button.

FIGURE 4: Setpoint Setup


In the "Output in Process" panel, click on the Heating Zone desired. The Sensor Input will be automatically selected. In the "Setpoint Occupied" field, the software will display the current setpoint. Due to the ability of the sensor slide bar to adjust within a setpoint range, **no single occupied setpoint is input into the software.** The setpoint cannot be input in the "Setpoint Occupied" box, it is only displayed. The allowable range is set by following the steps on *Page 18, Section 3.8* and *Page 13, Section 3.4*. The program checks setpoint range (See *Page 13, Section 3.4*) and the occupied setpoint adjustment Low and High (See *Page 18, Section 3.8*) and will calculate the desired setpoint based on the zone sensor's slide bar position.

In the "Setpoint Offset" area, enter the "On-Below" and "Off-Above" values. "On-Below" is the number of degrees below the setpoint at which the heat will turn on. "Off-Above" is the number of degrees above the setpoint at which the heat will turn off. For example, if the setpoint is 65° and the "On-Below" is set at 1.0 and the "Off-Above" is set at 2.0, the heat will turn on at 64° and stay on until the temperature reaches 67°. Do not set both values at 0.0, this will result in short cycles and will result in increased electricity usage from the vacuum pump turning on and off frequently. Generally a span of 2° or 3° keeps a tight tolerance on the zone temperature without causing short heating cycles.

In the "Night Setback" panel, enter the setback temperature setpoint in the "Heating" field. The setback setpoint is the temperature that will be maintained in the heating zone during a non-occupied or setback period. The setback temperature setpoint is generally 5°-10° lower than the occupied temperature setpoint.

In the "Control Mode" panel, click on "Heating". If "Disable" is chosen, the set points will be ignored and the heaters will turn on and off by time schedules only.


After assigning setpoints for all the heating zones, click on the "Send to Controller" button. Click on the green "Exit" button.



3.4 Setpoint Range

On the menu bar, click on "Program." On the drop down menu, click on "Setpoint Range." Click the "Edit" button.

FIGURE 5: Setpoint Range



In the "Output in Process" panel, click on the Heating Zone desired.

The "Slide Bar Range Min/Max" fields, will be set according to the values input in the Zone Setpoint adjustment "Low" and "High" boxes on the "Sensor Setup" screen. See *Page 18, Section 3.8*.

In the "Setpoint Range Min/Max" fields, type in the actual temperatures that the sensor can be adjusted to when using the slide bar. For example, if the desired occupied setpoint is 65° and +/- 5.0 was used for the "Slide Bar Range", then the "Setpoint Range Min" will be 60.0 and the "Setpoint Range Max" will be 70.0.

The "Sensor Input" should automatically be selected by the computer when the Desired Heating Zone was selected from the "Output in Process" panel. If the setting was accidentally changed, select the following settings with the "Sensor Input" drop down:


For Heating Zone 1: Select Input 4, "Zone 1 Setpoint"

For Heating Zone 2: Select Input 5, "Zone 2 Setpoint"

For Heating Zone 3: Select Input 6, "Zone 3 Setpoint"

"Reset Delay" should be set to 0005 sec. In the "Control Mode" panel, be sure "Direct" is selected, otherwise the setpoint feature will not function properly. After assigning ranges

for all the heating zones, click on the "Send to Controller" button. Click on the green "Exit" button.



3.5 Input/Output Titles

On the menu bar, click on "Program." On the drop down menu, click on "Input/Output Titles."

FIGURE 6: Input/Output Titles

Digital Outputs	Temperature Inputs	Digital Inputs
Output 1: Stock Room	Input 1: Stock Room Temperature	Input 1: Stock Room Override
Output 2: Loading Dock	Input 2: Loading Dock Temperatu	Input 2: Dock Override
Output 3:	Input 3:	Input 3:
Output 4:	Input 4: Zone 1 Setpoint	Input 4: Pressure Switch Status
Output 5:	Input 5: Zone 2 Setpoint	
Output 6:	Input 6:	
Output 7:	Input 7: BMS Override	
Output 8: Vacuum Pump Enable	Input 8: Outdoor Air Temperature	

Analog Outputs
Output 1: Vacuum Pump Speed
Output 2:
Output 3:
Output 4:

All Input and Output titles are preset. By clicking the "Edit" button, any of the titles may be edited. If you are not using all three zones, you may delete unnecessary titles as shown on Page 14, Figure 6.

Digital Outputs:

Output 1-3: Power Outputs to Burners in Zone 1-3.

Output 4-7: Not Used.

Output 8: Power Output to Pump Enable Relay in VFD Enclosure.

Temperature Inputs:

Input 1-3: Sensed Temperature in Zones 1-3.

Input 4-6: Setpoint for Zones 1-3 (Title *Only* used on "Setpoint Range" Screen)

Input 7: Building Management System Override Input.

Input 8: Sensed Outdoor Temperature.

Digital Inputs:

Input 1-3: Setpoint Override Button for Zones 1-3.

Input 4: Pressure Switch at Pump.


Analog Outputs:

Output 1: 0-10 V Signal to VFD.

Output 2-4: Not Used.

After editing titles, click on the "Send to Controller" button.


Click on the green "Exit" button.



3.6 Holiday Schedule


On the menu bar, click on "Program." On the drop down menu, click on "Holiday Schedule." Click the "Edit" button.

FIGURE 7: Holiday Schedules



Fifteen holidays may be programmed. During a holiday, the heating system will ignore regularly scheduled "occupied" setpoints and will maintain the setback setpoint for the entire day.

In the "Output Enable" panel, click on the zones that will observe the holidays. Notice that any customized titles as entered on the Input/Output Titles Screen (See Page 14, Section 3.5) are now shown in the Output Enable panel.




3.7 Timed Overrides

Each zone sensor has an override button. By pressing the button during a "setback" or "unoccupied" scheduled time, the zone will switch on to achieve the "occupied" temperature setpoint. On this screen, the duration of time that the override command is active is programmed. Pressing a zone sensor's override button during an occupied period will have no effect.

On the menu bar, click on "Program." On the drop down menu, click on "Timed Overrides." Click the "Edit" button.


FIGURE 8: Timed Overrides



In the appropriate field, enter the desired duration of time (in seconds) for the override period. To enable the overrides, check the Enable box. The overrides may be disabled by un-checking the "Enable" box. When overrides are disabled, the override button on the zone temperature sensors will have no function.

After entering timed overrides, click on the "Send to Controller" button.

Click on the green "Exit" button.



3.8 Sensor Setup

On the menu bar, click on "Program." On the drop down menu, click on "Sensor Setup." Click the "Edit" button.

FIGURE 9: Sensor Setup

	Sensor				
	Type	Low	High	Units	Decimal
Zone 1 Air Temperature	Thermistor	00	00	F	000.0
Zone 2 Air Temperature	Thermistor	00	00	F	000.0
Zone 3 Air Temperature	Thermistor	00	00	F	000.0
Zone 1 Setpoint	0-10k/0-5vdc	-50	50	Deg	000.0
Zone 2 Setpoint	0-10k/0-5vdc	-50	50	Deg	000.0
Zone 3 Setpoint	0-10k/0-5vdc	-50	50	Deg	000.0
BMS Override	Thermistor	00	00		000.0
Outdoor Air Temperature	Thermistor	00	00	F	000.0

☐ Celsius

Buttons: Edit, Exit

If celsius zone sensors (P/N 10081502) are being used, be sure that there is a check mark in the "Celsius" box.

For Zone 1, 2 and 3 Air Temperature, BMS Override and Outdoor Air Temperature use the following settings:

Type= Thermistor; Low=00; High=00


For Zone 1, 2, and 3 Setpoint (Occupied Setpoint Adjustment) use the following settings: Type= 0-10k/0-5vdc.

The setpoint adjustment is made by using the slide bar on the zone sensor. For Low and High, enter the number of degrees for the setpoint adjustment. NOTE: Do not type in a decimal point. For example, if the desired slide bar adjustment from setpoint is to be +/- 5°, then Low = "-50" and High = "50". The program will recognize a decimal point one place to the left of the number entered. For example, a 5° setpoint adjustment should be typed "50", which will be recognized by the program as "5.0".

To disable the sensor slide bar, set Low = 00 and High = 00.

Temperature units of measure (Units): Type in C, F or Deg in the "units" boxes if you wish for the unit of measure to appear next to the corresponding temperature display on the "board status" screen. The boxes may also be left blank. Since BMS override does not have a unit of measure, leave this "units" box blank.

Decimal place: For all rows, leave 000.0 in the "decimal" boxes. After completing the sensor setup, click on the "Send to Controller" button. Click on the green "Exit" button.



3.9 Global I/O Setup

On the menu bar, click on "Program." On the drop down menu, click on "Global I/O Setup." Click the "Edit" button.

FIGURE 10: Global Setup




Check mark the "Enable Global Communications" box, this will allow the central controller to access data from the satellite controllers.

Check mark the "Enable Global OAT" box, this will send the outside air temperature reading from the central controller to all satellite controllers.

NOTE: IF only one controller is being used, the "Enable Global Communications" and "Enable Global OAT" boxes can be either checked or unchecked with no difference in controller function.

In the "Board Count" field, enter the total number of controllers (central controller and all satellite controllers) on the network that are connected in the RS-485 communication chain. Click on the "Send to Controller" button. Click on the green "Exit" button.




3.10 History Mode

History mode allows data logging for the controller's inputs and outputs. A history log can be kept of any or all of the controller's inputs or outputs for a period of up to 92 days, logging is recorded every 15, 30 or 60 minutes. Logging input/output signals can help gauge system usage and measured temperatures. Note that the more inputs/outputs that are logged, as well as the frequency and duration of the history period, will affect the amount of data recorded.

On the menu bar, click on "Program." On the drop down menu, click on "History Mode."

FIGURE 11: History Mode



Click the "Edit" button.

Click on the input/output boxes that you wish to log.

Analog inputs:

1-3 are zone temperatures for zones 1-3.

4-6 are sensor slide bar positions for zones 1-3.

7 is BMS Enable

8 is outside air temperature.

DI Time Accum(ulated):

Digital Inputs 1-3 are overrides for zone sensors 1-3. Digital input 4 is for the pump pres-

sure switch.

DO Time Accum(ulated):

Digital Outputs 1-3 are for the burner power signal for zones 1-3. 8 is for the vacuum pump power signal.

Adjust the "Days" slide bar to set the number of days of the history period.

Adjust the "Interval" slide bar to set the number of minutes between each reading.


Check mark the "History Enable" box to activate the data logging feature.

After entering all history criteria, click on the "Send to Controller" button.

Click on the green "Exit" button.


Note that each controller does not have enough memory to record every input/output for the entire 92 day period. Watch the blue memory bar on the screen to determine if the history log is too big for the controller's memory. If the text above the bar reads "out of range," reduce the number of inputs/outputs that are monitored, reduce the number of days in the history period or increase the interval between logging times.

3.11 Time/Date



On the menu bar, click on "Program." On the drop down menu, click on "Time/Date." Click the "Edit" button.


FIGURE 12: Time/Date



Type in the time, date and day of the week or click the "Display Computer Time" button to enter the same time that is kept by the PC. If there is more than one controller, click the "Synchronize all Clocks" button.

After entering the time/date, click on the "Send to Controller" button. Click on the green "Exit" button.

SECTION 4: STATUS MENU



4.1 Board Status

The board status screen displays all current ROBERTS GORDON® ULTRAVAC™ heating system settings and temperatures. This may be the screen that is most frequently viewed by the user to gather current system conditions.

On the menu bar, click on "Status." On the drop down menu, click on "Board Status."

FIGURE 13: Board Status

 A screenshot of the 'Board Status' window. The title bar reads 'Board Status Board Name = board1.TMS'. The window is divided into several panels:

- Universal Inputs:** Displays Stock Room Temperature (71.3), Loading Dock Temperature (71.3), Outdoor Air Temperature (24.9), and a status box (OFF).
- Setpoints:** A table showing occupied setpoints, slide bar positions, and setback setpoints for three zones.

	Occupied Setpoint	Slidebar Position	Setback Setpoint
Zone 1	75.2 Deg	0.2	68.0 Deg
Zone 2	77.1 Deg	2.1	68.0 Deg
Zone 3	.1 Deg	0.1	0.0 Deg
- Digital Output Status:** Shows Stock Room (ON), Loading Dock (ON), Vacuum Pump Enable (ON), and Call For Heat (OFF).
- Digital Input Status:** Shows Pressure Switch Status (ON) and BMS Override (OFF).
- Analog Output Status:** Shows Vacuum Pump Speed (ON, 9.996) with a corresponding progress bar from 60% to 100%.

 At the bottom, there is a checked 'Auto - Update' checkbox and an 'Exit' button.

Universal Inputs panel displays zone and outside air temperatures.

Setpoints panel displays the occupied setpoint and setback setpoint in each zone. "Slide Bar Position" values indicate how many degrees off of midpoint that the slide bar on the zone sensor is set at.

Digital Output Status panel shows whether power is on to the vacuum pump and burner zones. Text beside the zone status boxes indicate whether the zone is satisfying the occupied setpoint or the setback setpoint.


Digital Input Status panel shows the pressure switch and BMS enable status.

Analog Output Status shows the vacuum pump speed and status. The speed of the vacuum pump also indicates the percentage input rate of the burners that are on.

Check mark the Auto-Update box to continuously update current controller readings.

Click on the green "Exit" button.

SECTION 5: GRAPHICS MENU




As an alternate method of viewing the ROBERTS GORDON® ULTRAVAC™ system status, the information from the Board Status screen (See *Page 23, Section 4*) can be arranged on a drawing or picture of the area being monitored.


A Windows® Metafile (.wmf) can be assigned to a button on the graphics screen and the user can customize the status data to be viewed in conjunction with the drawing or picture. Data boxes showing zone temperature, setpoints, zone On/Off status etc. can be placed on the screen. Up to 33 different.wmf files can be accessed by the graphics feature for each job file. **To use the Graphics feature, the drawing or picture to be used must be in Windows® Metafile (.wmf) format.** For proper viewing of the entire Graphics Screen, your monitor must be at least set at 1024 x 768 pixels. After setting up the graphic screen, if the graphic displayed appears distorted, contact your local Roberts-Gordon distributor for assistance.

On the menu bar, click on "Graphics". Click on "Graphic View."


5.1 Programming Mode



Click on the "Graphics Mode" drop down. Click on "Programming Mode."



Click on the "Edit Graphics" drop down. Click on "Edit Graphics."

FIGURE 14: Graphics Edit Box Type Drop Down

Click on the "Choose Type" drop down. A list of types of boxes and buttons appears that allow for the creation of a custom status screen.

Setup Buttons: Buttons are displayed on the right side of the screen in the "Selector" panel. Each button represents a different graphic screen. A different Windows® Metafile (.wmf) can be assigned to each button. Up to 33 screen buttons can be created. This feature customizes the title of the button as well as assigning the Windows® Metafile to be displayed when the button is clicked.

Analog Input Box: Creates a data label that displays the status of any of the control panel's eight analog inputs. Inputs 1-3 show zone temperatures; inputs 4-6 show zone sensor slide bar positions; input 7 shows BMS enable On/Off; input 8 shows outdoor air temperature.

Digital Input Box: Creates a data label that displays the status of any of the four digital inputs. Inputs 1-3 show zone sensor override button status; input 4 shows pressure switch status.

Digital Output Box: Creates a data label that displays the status of any of the digital outputs. Only digital outputs 1-3 and 8 are used. Outputs 1-3 show zone On/Off status; output 8 shows vacuum pump On/Off status.

Analog Output Box: Creates a data label that displays the 0-10V value generated by the control panel for speed control of the vacuum pump. Only output 1 is used. 0V will indicate minimum pump speed and 60% burner firing rate, 10V will indicate maximum pump speed and 100% burner firing rate.

Setpoint Box: Creates a data label that displays the occupied setpoint for any zone.


Schedule Box: Creates a data label that displays the BEGIN or END time of a time schedule.

Schedule Position Box: Not Used.

5.1.1 Setup Buttons

On the "Choose Type" drop down, click on "Setup Buttons."

FIGURE 15: Graphics Setup Buttons




In the "Select Button to Edit" field, click on the button to be customized (button 0 is the top button in the "Selector" panel; button 33 is the button just above the "Exit" button).

Type the title to appear on the button in the "Enter Button Text" field.

Click "Browse" to locate the Windows® Metafile that will be displayed when the button is clicked. Select the file and click "Open", the file path will be displayed in the "Enter Image Path" field.

Click "Save to File" then click "Close". In the "Selector" panel, click "Exit."

Re-enter the graphics screen and click on the customized button to display the background graphic.


FIGURE 16: Graphic Example

Repeat *Page 26, Section 5.1.1* to create more graphic setup buttons as desired. Each different graphic setup button can display a separate graphic file.
 Proceed to *Page 28, Section 5.1.2* to create data labels for this graphic.

5.1.2 Analog Input Label

On the "Choose Type" drop down, click on "Analog Input Box".

FIGURE 17: Graphics Analog Input Box



Since the analog input label will be placed on top of the Windows® Metafile graphic, choose the graphic on which the label should appear by clicking on the appropriate selection in the "Select Button to Edit" field. Click "Add New."

In the "AI# (1-8)" field, enter the analog input to be displayed (See Page 24, Section 5.1 for details about the analog inputs).

Title the name of the label in the "Enter Name" field. This name will not be displayed on the screen, but the name is used to create a file name associated with this label.

In the "Board Address" field, enter the number of the board from which the data is to be retrieved. The board number corresponds to the position of the dip switches on the control board (see the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) for details about the dip switch settings).

Enter the X and Y position where the label will be placed on the screen. When the cursor is moved across the screen, the X and Y position of the cursor is shown in the bottom left corner of the screen. Move the cursor to the desired location of the label on the screen and enter the coordinates in the X and Y fields.

The width and height of the label can be customized, however, they are not required to be changed from the default settings.

Click "Create Label." The box will appear on the screen at the location of the X and Y

coordinates.

If the label has not been placed in the exact location desired, place the cursor over any part of the picture, **except the open window or the data label that was just created**. Left click and hold, the cursor will grab the data label. While holding, drag the data label to the desired position and release.

To create more Analog Input labels, click on the desired button in the "Select Button to Edit" box, then click "Add New" and enter the required settings. Repeat process until all the desired analog inputs labels have been created.

5.1.3 Digital Output Label

On the "Choose Type" drop down, click on "Digital Input Box".

Setup is similar to Analog Input Label, *See Page 28, Section 5.1.2* for details.

See Page 24, Section 5.1 for details about the digital inputs.

5.1.4 Digital Output Label

On the "Choose Type" drop down, click on "Digital Output Box".

Setup is similar to Analog Input Label, *See Page 28, Section 5.1.2* for details.

See Page 24, Section 5.1 for details about the digital outputs.

In the "DO# (1-8)" field, only digital outputs #1-3 and #8 are used.

5.1.5 Analog Output Label

On the "Choose Type" drop down, click on "Analog Output Box".

Setup is similar to Analog Input Label, *See Page 28, Section 5.1.2* for details.

See Page 24, Section 5.1 for details about the analog outputs.

In the "AO# (1-4)" field, only analog output #1 is used.

5.1.6 Setpoint Label

On the "Choose Type" drop down, click on "Setpoint Box".

Setup is similar to Analog Input Label, *See Page 28, Section 5.1.2* for details.

In the "OSP (1-8)" field, only setpoints (OSP) 1-3 are used.

5.1.7 Schedule Label


On the "Choose Type" drop down, click on "Schedule Box".

Setup is similar to Analog Input Label, *See Page 28, Section 5.1.2* for details.

In the "Schedule# (0-23)" field, enter the appropriate number that corresponds to the "On" or "Off" time that is to be displayed. *See Page 9, Figure 3*, observe the "On" and "Off" times in the "Enter Schedules" panel. If #0 is entered in the "Schedule# (0-23)" field, the box created will display the "On" time for schedule 1; #1 will display the "Off" time for schedule 1 and so on. If #23 is entered in the "Schedule# (0-23)" field, the box created will display the "Off" time for schedule 12.

5.1.8 Schedule Position Label


The "Schedule Position Box" option is not used.



5.2 Status Mode

After programming all graphics as described on Page 26, Section 5.1.1 through Page 29, Section 5.1.7, click on the "Graphics Mode" drop down. Click on "Status Mode."


FIGURE 18: Graphic Example with Data Boxes



The data labels will update and display current status values. Whenever viewing system status on the "Graphics View" screen, be sure that "Status Mode" is selected so that data labels are continually updated.

If data labels are not updating, exit Graphics. On the tool bar, click on "Status", then click on "Board Status". When the "Board Status" window opens, be sure that the "Auto - Update" box in the lower left corner of the window is checked.

SECTION 6: ALARMS MENU



6.1 Temperature Alarms

Any input temperature can be set to generate an alarm that will be sent to any pager phone number along with an alarm message. **Pager notification and messaging can only be used if the central controller has the optional modem installed.** Alarms can be created for zone temperatures that are either above or below a desired setpoint. Up to eight custom alarms can be created.

On the menu bar, click on "Alarms." On the drop down menu, click on "Temperature Alarms."

Click the "Edit" button.

From the drop down, select the sensor input to be monitored. Generally, the only monitored inputs will be zone temperature inputs.

FIGURE 19: Alarm Selection




FIGURE 20: Temperature Alarms

Select alarm number in the "Alarm in Process" panel, the alarm condition beneath the "Sensor Input" drop down, and setpoint in the "Temperature Alarm Settings" panel.

Click on "Enable Global Alarms" in the "Alarms Enable" panel. "Enable Local Alarms" will enable alarms for the controller that you are currently accessing. "Disable" will inactivate the alarm feature.

If the pager dial out feature is desired, enter the required dial out settings, pager message and check the "Alarm Dialout Enable" box.


Click on the "Send to Controller" button.

Click on the green "Exit" button.

If alarm condition occurs, the "Global Alarm Status" box will indicate that an alarm has occurred. After the condition has been cleared, click "Edit" and "Reset Alarm" then "Send to Controller".

DISCLAIMER: The ROBERTS GORDON® ULTRAVAC™ features an alarm capability in the event the temperature drops below a specified setpoint. This feature is designed to alert the user of a situation where the heating system is unable to offset building heat loss. The alarm should not be relied upon to safeguard against heat deficiency. The alarm is for convenience purposes only. In no event shall Roberts-Gordon be responsible for any damage due to any failure.


SECTION 7: HISTORY MENU



7.1 Retrieve History Data to File

On the menu bar, click on "History." On the drop down menu, click on "Retrieve History Data to File."


FIGURE 21: History - Retrieve Data to File



In the "History Selections" panel, select the data to be retrieved. See *Page 21, Section 3.10* for an explanation of the selections.


In the "System Setup" panel, select the start and end dates for the data to be retrieved. Select whether the data is to be collected from one controller or all controllers.

Click the "Retrieve Data" button.

FIGURE 22: History - Data File Name

Select a file name and address and a Microsoft® Excel (.csv) file will be saved with the name and file location of your choice.

SECTION 8: COMMUNICATIONS MENU




8.1 Connect

See Page 18, Section 3.8.

8.2 Send File Data to Controller

To send a new board file to the controller, open the desired file from the "File" drop down menu on the menu bar. After the file is open, connect to the desired board. Once connected, click on "Communications" on the menu bar, then click on "Send File to Controller" from the drop down menu.

FIGURE 23: Send File to Controller



If the job file has multiple board files and you wish to send all the board files, click on "All Board Files". If only the current board file is required to be sent to the controller, click on "Current Board File".

Click on desired selections and then click the "Restore System Data" button.

8.3 Retrieve Controller Data to File

A controller's on board stored settings can be downloaded into an open board file. To create a file from existing board data, open "Edit Job" from the "File" drop down menu on the menu bar. Add a new board file.

On the menu bar, click on "Communications." On the drop down menu, click on "Retrieve Controller Data to File."


Click on desired selections and then click the "Retrieve Data" button.

8.4 Hang-up

Before exiting ROBERTS GORDON® ULTRAVAC™ Software or shutting down the computer, be sure to terminate communications from the controller by using the hang-up feature. Hang-up disconnects communication with the controller(s).

The controller cannot communicate with two PCs' at the same time. For example, a PC cannot direct connect to a controller while another PC is connected via modem.

FIGURE 24: Hang-Up




On the menu bar, click on "Communications."

On the drop down menu, click on "Hang-up" to disconnect communication to the controller.

If the software is turned off without hanging up, the connection will be terminated, even though the "Hang-Up" feature was not selected.

SECTION 9: FILE MENU

FIGURE 25: File Drop Down Menu



9.1 New Job

If multiple buildings (jobs) are to be accessed, a job file must be created for each location. On the menu bar, click on "File". On the file drop down menu, click "New Job".




FIGURE 26: New Job System Setup

 A screenshot of the "System Setup" dialog box. It contains several input fields: "System Name", "Phone Number", "IP Address", and "IP Port". Below these is a section labeled "How Many Boards Are Connected ?" with a small input box. At the bottom, there are three buttons: "Add New Job", "Save", and "Exit".

Click on the "Add New Job" button. Enter system(job) name, phone number (if using modem communications method), number of controllers, IP address and IP port (if using TCP/IP module communication method) in the appropriate fields. If phone number, IP address or IP port are needed but not known, the information may be entered later on the "connect" screen.

Generally, jobs with multiple controllers will share the majority of the programmed options with few changes from board file to board file. Since this usually holds true, enter "1" in the "How many boards are connected?" box. After programming one board file, the programmed board file can be copied so that programming time can be minimized. Copying board files is detailed on *Page 40, Section 10.1*.

If you do not want to copy settings from the first board file to the rest of the board files, in the "how many boards are connected?" box, enter the total number of controllers on the

job. In this case, multiple board files will automatically be created and each controller and board file will have to be programmed separately.

Click the "Save" button. Click "Exit". A job file will be created in the C:\Program Files\Roberts Gordon\UltraVac" folder, ("C" being your PC's hard drive.) The file already contains the number of board files that were specified in the "How Many Boards are Connected" box.

Close the ULTRAVAC™ software program, then reopen it. This will refresh the software with the new job name and board files that were just created.

As shown on *Page 6, Section 2.3*, double click on the correct job name and connect to the central controller.

Program the central controller (board1.TMS) as shown in *Section 3*.

After fully programming settings for the central controller (board1.TMS), See *Page 40, Section 10.1* for programming other (satellite) board files.


9.2 Open Job

To access a different job file, click on "Open Job". Double click on the job name, then double click on the board file name for the controller to be accessed. The "Connect" window will open. See *Page 6, Section 2.3* for correct instructions.

9.3 Edit Job

After creating a new job (see *page 37, section 9.1*) the job file can be edited to accommodate changes. On the menu bar, click on "File". On the drop down menu, click on "Edit Job".

FIGURE 27: Edit Job




If any new jobs were created as shown on *Page 37, Section 9.1*, the new job names will appear in the "Edit Job Name" panel under the "Ultravac" folder. In *Figure 27*, no new jobs were created so only the factory programmed default job name appears. The default job name is "UltraVac Demo". To customize the job name, click on the "UltraVac Demo" file in the "Edit New Job Name" panel. Click in the yellow text box under "Enter New Job Name" and edit the name. Click on the "Save Job Name" button to save the new name.

9.3.1 Add New Board Files

Do not add new board files if you are copying board files as described on Page 37, Section 9.1 and on Page 40, Section 10.1. If the job has multiple controllers, and you wish to program each controller separately instead of copying board files, additional board files must be added (one board file for each controller). To add a board file, click on "board1.TMS" in the "Edit Board File Name" panel. Click on the "Add New Board File" button.

FIGURE 28: Add New Board File



New file name "board2.TMS" will appear in the "Edit Board File Name" panel. To add additional board files, repeat *Section 9.3.1*.

Add board files until the number of files matches the number of controllers on the network that are connected in the RS-485 communications chain. The number in the board file name will correspond to the controller "address" which is set by the board identification dip switch on the controller (see the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual P/N 10081601NA for details.)

The new board files will have default programming and will have to be programmed individually while "connected" to the corresponding controller. To copy existing programmed board files, see *page 40, section 10.1*.

9.3.2 Delete Board File

To delete a board file, click on the file name in the "Edit Board File Name" panel, then click on the "Delete Current Board File" button.

9.3.3 Edit Board File Name

To edit a board file name, click on the file name in the "Edit Board File Name" panel, then edit the file name in the "Enter New Board Name" field. You must keep the number suffix and ".tms" extension. Only edit the part of the file name before the number suffix. i.e. edit only "board". The number suffix and ".tms" extension are critical for board addressing purposes.

9.4 Delete Job

To delete a job file, exit ULTRAVAC™ Software. On the PC's desktop, double-click on "My Computer". Navigate to C:\Program Files\Roberts Gordon\Ultravac; all job files should appear as folders. Delete the folder of the unneeded job file.

SECTION 10: MULTIPLE CONTROLLERS

10.1 Copying board1.TMS Board File for Jobs with Multiple Controllers

As mentioned on *Page 37, Section 9.1*, for most jobs that have multiple controllers, each of the controllers usually will need identical settings (internal and external design temperature, time schedules, setpoints, setpoint ranges, holiday schedules, etc.). Since this is usually the case, the easiest way to program multiple controllers is to first program the central controller and then copy the board file (board1.TMS) to make board files for the remaining controllers.

After programming of the central controller, ensure that all of the settings that you have programmed into the PC are sent to the controller by turning to *Page 35, Section 8.2* and following the instructions to send the file data to the current board file.

All of the settings programmed in the PC for the central controller are saved on the PC in a file called "board1.TMS". To save time, verify that the central controller is COMPLETELY programmed before "board1.TMS" is copied to make additional board files.

Exit from the ULTRAVAC™ Software.

A board file must be created for each controller on the job. The dip switch setting on the controller circuit board and the board file name will dictate which board file applies to each controller. For instance, the controller with the dip switches set for address 2 will use a board file named "board2.TMS", a controller addressed as 3 will use a file called "board3.TMS", and so on. Refer to the ROBERTS GORDON® ULTRAVAC™ Installation Manual (P/N 10081601) for controller dip switch setting details.

Copy "board1.TMS" to create additional board files by:

1. Navigate to C:/Program Files/Roberts Gordon/Ultravac. If you have successfully created a new job as detailed on *Page 37, Section 9.1*, there will be a folder with the same name as the job that was created.
2. Open the folder. The folder will contain one file named "board1.TMS".
3. Right-click on the file and select "Copy" from the dropdown.
4. Right-click in the open area in the window and select "Paste" from the dropdown.
5. Repeat the process until the number of files on the screen equals the number of controllers on the job.
6. Right-click one of the copied files and rename it "board2.TMS". The file name is case sensitive and MUST use this exact naming convention. No extra or alternate characters or spaces may be added to the file name.
7. Repeat the file re-naming process until each file is renamed. The number of files must equal the number of controllers on the job. There must not be any gaps in the sequential numbering convention of the file names. For instance if there are 4 controllers on the job, there must be a board1.TMS, board2.TMS, board3.TMS and board4.TMS file.




Exit from the current window and open the UltraVac Software by double-clicking on the black Roberts-Gordon UltraVac™ icon. When the "Connect" window appears, the job name that was created will appear in the white field on the right side of the window. Click on the job name and all of the file names that were created and re-named for all of the controllers will appear in the grey field on the left of the screen. Connect to the controllers, see *page 6, section 2.3*.

Close the "Connect" window and notice "Status: ON LINE" in the lower right of the screen. This means that a connection is made to the controller network. Click on one of the board

file names in the grey panel on left of the screen. This will highlight the file name which indicates that the next selection made on the tool bar at the top of the screen will apply to the controller using that file name.

FIGURE 29: Selecting Board 2 File



For instance, if board2.TMS is highlighted and then Status/Board Status is selected from the tool bar, then the status screen for controller 2 will appear.

10.1.1 Edit Satellite Board File Settings

If any board files require different settings from the copied "board1.TMS" file, click on the appropriate board file in the bar on the left side of the screen, the board file bar is shown in Figure 29. Edit settings as necessary, refer to Section 3 through 7.


One setting that MUST be changed on all board files except the "board1.TMS" file is the outside air temperature sensor setup. See Page 42, Section 10.2 for details.

10.2 Outside Air Temperature Setup for Satellite Controllers

For jobs with more than one controller, the central controller (controller #1) will be using an outside air sensor. The remaining controllers will share the outside air temperature signal with the central controller. **For all satellite controllers (every controller except controller #1), the outside air sensor setup screen must be altered.** Click on board 2.TMS on the left of the screen.

Verify that the PC is online with the controller, check the lower left corner of the screen for "Status: ONLINE". Select "Sensor Setup" from the "Program" drop down menu. Click the "Edit" button. Change the "Outdoor Air Temperature" type to "virtual" from the "Type" drop down menu.

FIGURE 30: Satellite Controller Outside Air Sensor Setup




Click the "Send to Controller" button. Click the green "Exit" button. If the board1.TMS file has been copied to board2.TMS, make any other changes to customize board 2, i.e.: input/output titles, setpoints, time schedules, etc. Repeat this procedure for all board files except for "board1.TMS".

SECTION 11: MANUAL ON/OFF SCREEN

Manually overriding the controller power output function can be a useful tool. The "Manual ON/OFF" screen is typically used during the equipment installation process for initial system commissioning.

FIGURE 31: ON/OFF Screen



To access the "Manual ON/OFF" screen, the ULTRAVAC™ software background screen must be visible with no other windows open. Press the "Alt + M" keys on the keyboard.

The "Manual ON/OFF" screen displays the power output status for power relays 1-3 and 8 on the controller's relay board. The current status of each zone or pump relay is displayed in the four colored fields on the right side of the screen. Notice that zone titles will be displayed as programmed on the "Input/Output Titles" screen. See Page 14, Section 3.5.

Status:

AUTO: Power output will be turned on and off according to controller's programmed settings.

ON: Power output will remain on regardless of controller's programmed settings or temperature setpoints.

OFF: Power output will remain off regardless of controller's programmed settings or temperature setpoints.

To change current power output status of a zone or pump, click on desired button. To turn "ON" burners, it is important to first turn "ON" the vacuum pump. Then turn "ON" the desired zone relay(s). This will allow the pump to create vacuum within the heating system

before attempting to light the burners. Clicking the "ON" button for zone power will not change status to "ON" unless the pump status is "ON" and the pressure switch has closed. When manual control is no longer desired, return vacuum pump power setting and zone power settings back to "AUTO". Set zone power for any unused zones to "OFF". Click "Exit" to close "Manual ON/OFF" screen.

Clicking the "Disable" feature will return all power settings to "AUTO".

SECTION 12: TCP/IP (LAN) COMMUNICATION MODULE INSTALLATION

The TCP/IP (LAN) Communication Module is an optional communication device that is included with every ULTRAVAC™ Central Controller with TCP/IP (LAN) Communication Module (P/N URVCCL). **If a TCP/IP (LAN) Communication Module is not supplied, skip this section.**


This section describes the proper procedure for installation of the TCP/IP (LAN) Communication Module. The device performs RS232 to TCP/IP conversion for connection of the ULTRAVAC™ Controller through a network connection. This controller will interface with network systems using TCP/IP protocol.

The TCP/IP (LAN) Communication Module is shipped complete with mounting rail for easy mounting. Please follow these instructions carefully to insure proper operation of the TCP/IP (LAN) Communication Module.

12.1 Module Details

Figure 32 shows the layout of the TCP/IP (LAN) Communication Module. The module contains one (1) RJ11 jack for RS232 communications with the central controller (address #1) and one (1) RJ45 ethernet communications jack for connection to a network.

FIGURE 32: TCP/IP Communication Module Details



12.1.1 Power / Run LED:

This is a red indicator light, and flashes when power is applied to the module and the unit is in the RUN mode. The LED flashes slow when module is in the RUN mode. The LED burns steady when in the PROGRAM mode.


12.1.2 Program Switch:

This is a 2 position toggle switch which controls the program/run function of the controller. Move fully *TOWARDS* "PROGRAM" for the PROGRAM mode, and fully *TOWARDS* "RUN" for RUN mode.

12.2 TCP/IP Communication Module

The module must be powered from the central control board, (address #1). Before making power connections, verify that the power switch on the ULTRAVAC™ Controller relay board is in the OFF position. The connection is made with a 1 pair, 18 gauge cable to the 5 Vdc power terminals on the control board. See Figure 33.

FIGURE 33: Power Connection to Central Control Board



12.3 Network Communications Connection

This controller will interface with network systems using TCP/IP protocols. The TCP/IP Communication Module connects to the network system as shown *on Page 56, Figure 36* and requires information from the network administrator for addressing and connection (See *Page 48, Section 13*).

NOTE: The module **MUST** be connected to the central control board (address #1) for proper system operation.

SECTION 13: TCP/IP (LAN) COMMUNICATION MODULE

The system is programmed through the "Isetup.exe" software program, and connects to the module with the direct connect cable package (P/N 10080410) included with the central controller.

To access the TCP/IP setup program, the ULTRAVAC™ Software must already be installed on the PC, See *Page 6, Section 2.2*. The TCP/IP setup program is found in c:\Program Files\Roberts Gordon\Ultravac.



Double click the icon labeled "Isetup.exe" and the ISETUP opening screen will appear.

Basyx Isetup Version: 1.0.13

Comm Port Baudrate

Default Settings

IP Address

Network Mask

Gateway

Port

Zone

Port Baud

☐ Zone Enable ☐ TCP IP Enable

Current Settings

IP Address

Network Mask

Gateway

Port

Zone

Mac Address

Port Baud

☐ Zone Enable ☐ TCP IP Enable

☐ IPM with Mac

☐ IPM Only

This is the opening setup screen for the TCP/IP Communication Module, which has no data in the "Current Settings" portion of the screen. However, data may appear in the "Default Settings" boxes if used in previous connections.

13.1 Set the Software Communications Parameters

Make sure that the Comm Port setting is correct for your computer, and that the baud rate is set to 2400 (default), as shown above. Click the down arrow or type in the Comm Port box to select the proper comm port number for your computer.

If communications are not able to be established as indicated on *Page 50, Section 13.3*, the comm number selected may be incorrect, try the next comm port number.

13.2 Set the System Type

The setup software is designed to work with several different products. Check the box labeled "TCP IP Enable" above the "CONNECT" button of the opening screen, shown below.

The screenshot shows the Basyx Isetup Version: 1.0.13 window. At the top, there are dropdown menus for "Comm Port" (set to 1) and "Baudrate" (set to 2400). Below these are two main sections: "Default Settings" and "Current Settings".

Default Settings:

- IP Address: [text box]
- Network Mask: [text box]
- Gateway: [text box]
- Port: [text box]
- Zone: [text box]
- Port Baud: [text box]
- ☐ Zone Enable
- ☒ TCP IP Enable

Current Settings:

- IP Address: [text box]
- Network Mask: [text box]
- Gateway: [text box]
- Port: [text box]
- Zone: [text box]
- Mac Address: [text box]
- Port Baud: [text box]
- ☐ Zone Enable
- ☐ TCP IP Enable

Below the settings sections are three buttons: "Reset", "Connect", and "Send Default Settings".


At the bottom, there are two checkboxes and two text boxes:

- ☐ IPM with Mac: [text box containing "Idle"]
- ☐ IPM Only: [text box]

13.3 Connect to the TCP/IP Communication Module

To connect to the module, make sure the module's power wires are connected to wire terminals and program switch is in the "PROGRAM" position. See *Page 46, Figure 33*. Connect the direct connect cable between the module's RJ11 and into the PC as shown on *Page 50, Figure 34*.

FIGURE 34: 9 Pin Adapter for PC



Verify that the program switch is set to the "PROGRAM" position as shown in *Figure 34*. The red Power/Run LED will turn on constant, not blinking.

The module must be set up to respond to the IP address assigned by the network administrator. The setup is performed with the module in the PROGRAM mode.

Click the "Connect" button near the bottom of the screen. The software will establish communications with the module, and the screen will indicate a successful connection by displaying "Comm Port Open" in the status box at the bottom of the screen as shown below. If communications are not established successfully, the comm port number at the top of the window may be incorrect, try changing the comm port number and clicking the connect button.

Basyx Isetup Version: 1.0.13

Comm Port: 1 Baudrate: 2400

Default Settings

IP Address:
Network Mask:
Gateway:
Port:
Zone:
Port Baud:
☐ Zone Enable ☒ TCP IP Enable

Current Settings

IP Address:
Network Mask:
Gateway:
Port:
Zone:
Mac Address:
Port Baud:
☐ Zone Enable ☐ TCP IP Enable

Reset Connect Send Default Settings

☐ IPM with Mac
☐ IPM Only

No data will appear in the "Current Settings" portion of the screen. You may see the program default data in the "Default Settings" portion if this is not the initial setup of the board. You are now ready to retrieve any existing settings from the module.


13.4 Retrieve the Existing TCP/IP Module Settings

The system will retrieve the existing TCP/IP settings, if any, and display the Mac Address of the module.


THE NEXT STEP MUST BE FOLLOWED CAREFULLY!

1. While still connected to the module, toggle the program switch on the module to "RUN" then back to "PROGRAM" (See Page 52, Figure 35).

FIGURE 35: Toggle the Program Switch



The system will retrieve the existing TCP/IP settings, if any, and display the Mac Address of the module. A pop-up message box when the retrieval is complete.



Click on "OK" to acknowledge and close the message box.

The system will now display the retrieved settings in the "Current Settings" portion of the screen.

Basyx Isetup Version: 1.0.13

Comm Port **1** Baudrate **2400**

Default Settings	Current Settings
IP Address	192.168.1.20
Network Mask	255.255.255.0
Gateway	192.168.1.20
Port	4675
Zone	1
Port Baud	19200
<input type="checkbox"/> Zone Enable <input checked="" type="checkbox"/> TCP IP Enable	<input type="checkbox"/> Zone Enable <input checked="" type="checkbox"/> TCP IP Enable

☐ IPM with Mac TCP IP Enable Received Transfer Complete

☐ IPM Only j192.168.1.20|255.255.255.0|192.168.1.20|4675|1|0|00:90:c2:c8:05:4e|-7936|0|

13.5 Enter the New TCP/IP Communication Module Settings

If your network requires it, the Mac Address for the module will be displayed at the bottom of the "Current Settings" portion of the screen. Provide your system administrator with this address for completion of the network setup.

For TCP/IP connection, you must change the TCP/IP address to match the static TCP/IP address which is **provided by your system or network administrator**.

To change the settings, place the cursor in the IP Address bar in the "Default Settings" portion of the screen.

Enter the proper information as required for your network connection (using the TAB key to move between entries):

- IP Address This must be a **static IP address** through your network.
- Network Mask See your network administrator.
- Gateway See your network administrator.
- Port This is a software port and is typically 4675 (as shown).
See your network administrator if you question this port address.
- Zone Set to "1".
- Port baud Set to 19200.
- TCP IP enable Check this box. No checks should appear in any other boxes (Zone enable, IPM with Mac, IPM only).

Enter your network administrator's settings into the fields in the "Default Settings" panel. The system screen should typically appear as follows at this point: (numbers in the fields on the "Current Settings" and "Default Settings" may vary depending on the settings entered from your network administrator).

Basyx Isetup Version: 1.0.13

Comm Port: 3 Baudrate: 2400

Default Settings

IP Address: 192.168.1.30
 Network Mask: 255.255.255.0
 Gateway: 192.168.1.30
 Port: 4675
 Zone: 1
 Port Baud: 19200

☐ Zone Enable ☒ TCP IP Enable

Current Settings

IP Address: 192.168.1.20
 Network Mask: 255.255.255.0
 Gateway: 192.168.1.20
 Port: 4675
 Zone: 1
 Mac Address: 00:90:c2:c8:05:4e
 Port Baud: 2400


☐ Zone Enable ☒ TCP IP Enable

Reset Connect Send Default Settings


☐ IPM with Mac TCP IP Enable Received Transfer Complete
☐ IPM Only j192.168.1.20|255.255.255.0|192.168.1.20|4675|1|0|00:90:c2:c8:05:4e|7936|0|

13.6 Download the New Module Settings

Verify that the entered information is correct and click on the "Send Default Settings" button at the bottom of the screen to download the new settings to the module. Once the download is completed, the screen will again display the pop-up message box with "Data Sent And Mac Address Received Transfer Complete".



Click on "OK" to acknowledge and close the message box, and notice the status box at the bottom of the screen also indicates that the transfer is complete. The system will now display the new settings in the "Current Settings" portion of the screen as shown: (numbers in the fields on the "Current Settings" and "Default Settings" of the screen may vary depending on the settings entered from your network administrator).




This completes the software setup of the TCP/IP Communication Module.

13.7 Completing the Installation

1. Verify that the current settings are correct and that the LED on the IPM is flashing.
2. Connect the module to the central control board (address #1). The connection is made with a standard 4 conductor telephone cord (included with the module). The telephone cord is plugged into the RJ11 port on the module, and connects to the control board's RJ11 connector marked "DIRECT RS232".
3. Place the program switch in the RUN mode and close the Isetup program on your PC.
See Page 52, Figure 35.
4. Connect ethernet cable into RJ45 jack on the module.
5. Run/CPU light should flash slow.
6. Return to *Page 6, Section 2.3 Software "Connect" Window.*

FIGURE 36: Communication Port Connections



SECTION 14: BACNET® CONTROLLER PROGRAMMING

Each BACnet® Controller is custom programmed before it is shipped. The custom program allows the controller to interface with all of the ULTRAVAC™ controllers installed at the jobsite. The total number of ULTRAVAC™ controllers (including the central controller and all satellite controllers, but not including the BACnet® Controller), the job name and location are submitted to Roberts-Gordon LLC upon placing the order for the BACnet® Controller. This information should be submitted on the BACnet® Controller order form. See *Page 58, Figure 37* for order form.

FIGURE 37: BACnet® Order Form



Please complete this form and submit with your order for the ROBERTS GORDON® ULTRAVAC™ BACnet® Control (P/N URVBNC).

RG Rep Name: _____ Rep PO #: _____

Job Name: _____

Job Location: _____

Total Number of ULTRAVAC™ Controllers: _____

(Not including BACnet® Control)

There are references in this form to various trademarks. All trademarks mentioned herein, whether registered or not, are the property of their respective owners. Roberts-Gordon LLC is not sponsored by or affiliated with any of the trademark or registered trademark owners, and make no representations about them, their owners, their products or services. Roberts-Gordon LLC is not sponsored by or affiliated with BACnet®.

Installation Code and Annual Inspections:

All installation and service of ROBERTS GORDON® equipment must be performed by a contractor qualified in the installation and service of equipment sold and supplied by Roberts-Gordon LLC and conform to all requirements set forth in the ROBERTS GORDON® manuals and all applicable governmental authorities pertaining to the installation, service and operation of the equipment. To help facilitate optimum performance and safety, Roberts-Gordon LLC recommends that a qualified contractor conduct, at a minimum, annual inspections of your ROBERTS GORDON® equipment and perform service where necessary, using only replacement parts sold and supplied by Roberts-Gordon LLC.

Further Information: Applications, engineering and detailed guidance on systems design, installation and equipment performance is available through ROBERTS GORDON® representatives. Please contact us for any further information you may require, including the Installation, Operation and Service Manual.

These products are not for residential use.

© Roberts-Gordon LLC

Printed in the U.S.A

P/N URVBNCFNA Rev. Orig



Please complete this form and submit with your order for the ROBERTS GORDON® ULTRAVAC™ BACnet® Control (P/N URVBNC).

RG Rep Name: _____ Rep PO #: _____

Job Name: _____

Job Location: _____

Total Number of ULTRAVAC™ Controllers: _____

(Not including BACnet® Control)

There are references in this form to various trademarks. All trademarks mentioned herein, whether registered or not, are the property of their respective owners. Roberts-Gordon LLC is not sponsored by or affiliated with any of the trademark or registered trademark owners, and make no representations about them, their owners, their products or services. Roberts-Gordon LLC is not sponsored by or affiliated with BACnet®.

Installation Code and Annual Inspections:

All installation and service of ROBERTS GORDON® equipment must be performed by a contractor qualified in the installation and service of equipment sold and supplied by Roberts-Gordon LLC and conform to all requirements set forth in the ROBERTS GORDON® manuals and all applicable governmental authorities pertaining to the installation, service and operation of the equipment. To help facilitate optimum performance and safety, Roberts-Gordon LLC recommends that a qualified contractor conduct, at a minimum, annual inspections of your ROBERTS GORDON® equipment and perform service where necessary, using only replacement parts sold and supplied by Roberts-Gordon LLC.

Further Information: Applications, engineering and detailed guidance on systems design, installation and equipment performance is available through ROBERTS GORDON® representatives. Please contact us for any further information you may require, including the Installation, Operation and Service Manual.

These products are not for residential use.

© Roberts-Gordon LLC

Printed in the U.S.A

P/N URVBNCFNA Rev. Orig

Each BACnet® controller is supplied with a printed report called a Points List. The Points List lists all of the programmed data addresses. The information from the Points List must be communicated to the controls manager for use in configuring the third party building controls software. This documentation is intended for the contractor to leave with the controls manager or end user upon commissioning of the ULTRAVAC™ system. Refer to the BACnet® Controller User Manual for onsite programming instructions.

14.1 PC Requirements

The PC used for programming must have:

1. Hardware

Ethernet network - a TCP/IP enabled PC with a network card is required.

The network card must support 10Mbit/s Ethernet.

2. Software

Programming must run one of the following operating systems:

DOS, Windows 95 (SR2 upwards), Windows 98, 2000, NT, XP

14.2 Communication Method

The PC can be connected to the BACnet® Controller by:

Ethernet Port

The Ethernet port can be used for configuration and troubleshooting, as well as for Protocols that require an Ethernet connection. Use standard Ethernet cables for this connection.


14.3 Installation and Setup

1. Re-address existing boards.

- a. Since the BACnet® Controller takes address 1, all the existing boards must be re-addressed. Start re-addressing the existing boards beginning with address 2. Address 1 becomes address 2, address 2 becomes address 3, address 3 becomes address 4, etc.
- b. Set Media Access Control address (dip switch).
- c. Plug Ethernet cable to the BACnet® Controller.
- d. Turn on a BACnet® Controller.


2. Connect to the FieldServer.

- a. Turn on a PC and connection to the FieldServer Using RUI (Ruinet) software.
- b. Select Start|Programs|FieldServer Utilities, use arrow keys alone or in conjunction with control key to change to other tiers. See *Page 60, Figure 38*.

FIGURE 38: Field Server Information

3. Change IP address.

- a. From the main menu, press "I" to enter the edit IP Address settings menu.
See Page 60, Figure 39.

FIGURE 39: Change IP Address

- b. Press "1" to modify the IP address of the N1.
- c. Type in a new IP address such as 192.168.0.35 and press <Enter>. If necessary, press "2" or "3" and change the Netmask or Gateway 1.
- d. Restart the FieldServer. Ruinet will display the main interactive menu again after FieldServer has restarted.

SECTION 15: TROUBLESHOOTING

15.1 Unable to Connect

Check continuity of the communication wire. Check for proper twisting and/or grounding of shield wires. See the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) external wiring diagrams for details.

If connecting via modem, *See Page 3, Section 2.1.1 and See Page 7, Section 2.3.3.* Verify that phone line is operational and connected to the central controller. See the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) external wiring diagrams for details. Verify that the modem chip is installed on the central controller. See the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) communications section.

If connecting via RS-485 converter, *See Page 3, Section 2.1.2 and See Page 7, Section 2.3.2.* Verify that the RS-485 converter is plugged in. Verify the RS-485/PC connection wiring in the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA). If connecting via direct connect, *See Page 4, Section 2.1.3 and See Page 7, Section 2.3.2.* Verify a secure connection between 9 pin connector and PC; 7' cable and 9 pin connector; 7' cable and controller.

15.2 Sensor Temperatures

Zone temperature or outdoor temperature reads "ON" or reads a very high temperature on the status screen. Check the analog input for the sensor temperature input (analog inputs 1-3 for zone sensors, analog input 8 for outdoor sensor). Reverse the wires at the input that has the incorrect reading. On the sensor setup screen, verify "type" is set to "thermistor". *See Page 18, Section 3.8.*

15.3 Zone Status On/Off

Zone 3 status displays "ON", even though there are only 1 or 2 zones installed: Close all windows in the software and access the manual on/off screen, (Alt + M). Click the "OFF" button for any unused zones. All other zones and vacuum pump must be set to "Auto".

15.4 Graphics Distorted

Verify that the file is in **Windows®** Metafile (.wmf) format, *See Page 24, Section 5.* ROBERTS GORDON® ULTRAVAC™ Software accepts "Windows®" Metafiles better than generic metafiles (.wmf). Generally, AutoCAD® can export **generic** metafiles that can be imported into a vector graphics drawing program such as Adobe® Illustrator® or Macromedia® Freehand®, then re-exported as a **Windows®** Metafile.

15.5 Temperature Alarms Reset

If an alarm condition occurs and the "Alarm Reset" button is clicked, then the alarm activates again. The alarm condition must first be eliminated before an alarm reset will work. *See Page 31, Section 6.1.*

15.6 Setting Changes Not Saved

If settings have been changed on any screen and have not been saved, the next time the screen is accessed: verify that the "Edit" button is clicked first; edit the settings; then click "Send to Controller"; then wait for the red "Updating" button to change to a green "Exit" button twice before clicking on the "Exit" button.

15.7 Current Conditions Are Not Updating

While viewing the board status screen or the graphics view screen, the incoming data from the controller can be seen updating in the lower left portion of the screen, next to "Status: ONLINE." If data is not updating, go to the "Board Status" screen and check mark the "Auto-Update" box. If the box is checked and the data is still not updating, close the software and re-connect and/or press the reset button on the control board. See the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) for reset button details.

15.8 BACnet® Controller

If the BACnet® controller does not connect to a field server, see the Utility User Manual Ruinet Appendix A, troubleshooting section.

15.9 Burner or Pump Operation

See the ROBERTS GORDON® ULTRAVAC™ Installation, Operation and Service Manual (P/N 10081601NA) troubleshooting section.

SECTION 16: THE ROBERTS GORDON® ULTRAVAC™ LICENSE AGREEMENT**THIS IS A LEGAL AGREEMENT.****PLEASE READ CAREFULLY BEFORE INSTALLING THE SOFTWARE.**

Use of the Software is subject to the terms of this End User License Agreement. By selecting YES and installing the Software, you accept and are bound by all the terms and conditions of the Agreement. If you do not agree with any term, condition or restriction as set forth by the Agreement, select NO, exit setup and return the Software to Roberts- Gordon LLC.

END USER LICENSE AGREEMENT:

1. The Software is intended strictly for use with ROBERTS GORDON® heating equipment. Multiple installations of Software are allowed solely for use on computers required for interface, operation or control of ROBERTS GORDON® heating equipment.
2. Software demonstrations are provided for the sole use of prospective purchasers. Installation of software is allowed for demonstration of the system and product information purposes only. The Software is intended solely to support the sale of ROBERTS GORDON® products and equipment. It is not intended for your personal use nor are you authorized to use same in such a manner as would be injurious to Roberts-Gordon's interests.
3. In no event shall any Software be distributed or electronically transferred to anyone other than the original purchaser. You may not sell, rent, lease or sublicense the Software. You may install the Software on multiple computers solely for the operation of ROBERTS GORDON® products and equipment, provided you keep intact all copyright and other proprietary notices. No right, title or interest in any downloaded Software is transferred to you as a result of any such downloading or copying. You may make one copy of the Software in machine-readable form solely for backup purposes; however this End User License Agreement and copyright notices as found on the original copy of the Software must be reproduced as well.
4. In no event shall you alter, merge, modify, adapt, translate, reverse engineer, disassemble, create derivative works or otherwise decode or manipulate the Software for any reason whatsoever.
5. This Software is being delivered to you "as is" and Manufacturer, Roberts-Gordon and their suppliers make no warranty, express, implied, or otherwise, including the warranties of merchantability or fitness for a particular purpose, as to its use or performance. There is no warranty that the Software is error-free or will operate without interruption. The Software is not designed, intended or licensed for use in hazardous environments requiring fail-safe controls.

Manufacturer and Roberts-Gordon specifically disclaim any express or implied warranty of fitness for such purposes. Some states do not allow the exclusion of implied warranties so the exclusion may not apply to you. This warranty gives you specific rights and you may also have other legal rights that vary from state to state.

6. User assumes all responsibility for the installation and operation of Software. In no event shall Manufacturer, Roberts-Gordon or their suppliers be liable to you or any third party for any indirect, special, incidental, punitive, cover or consequential damages arising out of the use or inability to use the Software based on any theory of liability including breach of contract, breach of warranty, tort (including negligence) product liability or otherwise, even if Manufacturer or Roberts-Gordon have been advised of the possibility of such damage and even if a remedy set forth herein is found to have failed of its essential purpose. Some states do not allow the limitation or exclusion of liability for incidental or consequential damages, so the above limitation may not apply to you and you may also have other legal rights that vary from state to state.
7. This End User License Agreement shall automatically terminate upon failure by you to comply with its terms. Manufacturer and Roberts-Gordon reserve the right to terminate and revoke this Agreement at any time. Upon termination you must destroy all copies of this software or return same to Manufacturer or Roberts-Gordon upon request.
8. The foregoing License gives you limited license to use the Software. Manufacturer retains all right, title and interest, including copyright and intellectual property rights, in and to the Software and all copies thereof. All rights not specifically granted in the End User Licensing Agreement are reserved by Manufacturer.

9. ROBERTS GORDON® ULTRAVAC™ and related marks are trademarks of Roberts-Gordon in the United States and/or other countries. Roberts-Gordon retains all right, title and interest, including copyright and intellectual property rights, to its heating equipment, services and attendant trade dress, trademarks, trade names, and service marks.

10. This Agreement is governed by the Laws of the State of New York, U.S.A. If any part of this Agreement is found void and unenforceable, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. You agree this Software will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration Act or any other export laws, restrictions or regulations.

© Roberts-Gordon LLC. All rights reserved.

